Register your product and get support at

www.philips.com/welcome




26PFL3404H/12
32PFL3404H/12
42PFL3604H/12
26PFL3404D/12
32PFL3404D/12
42PFL3604D/12


Quick Start


Q41G78308135B


PHILIPS



PHILIPS
TELEVISION
www.philips.com/welcome
PHILIPS
PHILIPS
UK only


1













2





3


①



AAA
x 2

②



Select language
Český
Български
Dansk
Deutsch
Ελληνικά
English
Español
Français
GUIDE
OPTIONS
OK
BACK
INFO
P/P






Select your country, then press OK.
Slovakia
Slovenia
Spain
Sweden
Switzerland
Turkey
UK
Ukraine
GUIDE
OPTIONS
OK
BACK
INFO
P/P



Select TV location.
Shop
Home
GUIDE
OPTIONS
OK
BACK
INFO
P/P



Start automatic installation.
This takes a few minutes.
Full Installation
Skip Installation


4





HDMI	
☆☆☆☆	
YPbPr & AUDIO L/R	
☆☆☆	
SCART	
☆☆	
AUDIO L/R & VIDEO IN	
☆	



HDMI
HDMI



EXT 1
(RGB/CVBS)


DVI
DVI
HDMI 1
AUDIO IN :
LEFT / RIGHT
HDMI 1 / DVI


AUDIO IN
SPDIF OUT


EXT 1
(RGB/CVBS)
EXT 2
(CVBS)
ANTENNA
IN
OUT
TO TV
AUX
DVD
R / RW
AUX
TO TV


MENU
FORMAT
INCR.SURR
MHEG
TELETEXT
SOURCE
DEMO
SUBTITLE
AD
GUIDE
OPTIONS
OK
BACK
INFO
P/P
P
1
2
3
4
5
6
7
8
9
0
SOUND
PICTURE
PHILIPS
TELEVISION
TV
EXT 1
EXT 2
EXT 3
HDMI 1
HDMI side
AV side
DVD VIDEO
DVD R/RW
Blu-ray Disc
DVI
• • •




LCD Television
user manual
Register your product and get support at
www.philips.com/welcome
PC & Mac
PHILIPS


www.philips.com/support